


GREENLUX®

the power of light...



WiFi SWITCH White

GXSH040

WiFi 2SWITCH White

GXSH041

WiFi SWITCH Black

GXSH042

WiFi 2SWITCH Black

GXSH043

User ▾



Welcome Home

Set your home location for more information >

Add Device

All Devices Tap + to add a smart device. ...

Got It



No devices

Add Device



Home



Smart



Me



Electrician

Socket

Lighting



Socket (Wi-Fi)

Socket (ZigBee)

Socket (BLE)

Large Home Ap...



Socket (NB)

Socket (other)

Small Home Ap...

Kitchen Appliances

Power Strip

Security & Sensors



Power Strip (Wi-Fi)

Power Strip (ZigBee)

Power Strip (other)

Exercise & Health

Switch

Video Surveillance



Switch (Wi-Fi)

Switch (ZigBee)

Switch (GPRS)

Gateway Control

Energy



You are advised to enable Bluetooth. Enable Bluetooth to add some Wi-Fi device...



Cancel

Select 2.4 GHz Wi-Fi Network and enter password.

If your Wi-Fi is 5GHz, please set it to be 2.4GHz. [Common router setting method](#)



2.4GHz



5GHz



Greenlux_free



.....



Next




Cancel

EZ Mode ⇌

Reset the device first.

Please turn on the device and confirm that indicator is blinking fast.

Attention: please complete pairing process within 3 minutes after device reset.



Resetting Devices >



Confirm indicator rapidly blink

Next



Cancel

Adding device...

Ensure that the Wi-Fi signal is good.



3%



Scan
devices.



Register on
Cloud.



Initialize the
device.



Cancel

Added successfully




1g WIFI Switch

Device added successfully



Done



User 

Welcome Home

Set your home location for more information >

All Devices

Salon



1g WIFI Switch



Home



Smart



Me